

## BA/BF FALCON GAUGE DASH POD

FITTING INSTRUCTIONS

Part No. SGPBABF

v20230628

## Important notes before installing:

- 1. All installation work should be done by a qualified professional to avoid damage to this product.
- This gauge dash pod may discolour or warp if exposed to direct sunlight for long periods. To avoid this, SAAS recommends using a sun shade to protect the dash pod and gauges from extreme heat.





 Carefully remove the original cover by prying it open with a flat object (screwdriver or similar). Clips are at the rear.



2. Remove the clips from underneath the original cover so they can be attached to the new gauge pod.



 Position clips around the gauge pod ready to mount back in place of the original part.



 Use electrical tape & run approx. three (3) rounds of tape around gauge body behind bezel. Add/reduce depending on tape thickness.



 Part of the plastic under the cover needs to be cut away as it interferes with the new gauge pod. While open, proceed to wire the gauges.



6. Gently and evenly push the new gauge dash pod into position ensuring the clips lock into place.

## **GRES** www.shopsaas.com

SAAS AUTOMOTIVE

25 Metrolink Circuit West, Campbellfield, Victoria, Australia 3061