



(1pc) PILLAR POD

Installation Instructions

v20220627

Important notes before installing:

- **CAUTION:** Some vehicles have air bags fitted behind the pillars and may require special tools for removal. Before you proceed, refer to the vehicle's service manual for correct removal procedure. It is **YOUR** responsibility to make sure the air bags (if fitted) are not obstructed in any way, and function as per manufacturer's specifications!
 - All installation work should be done by a qualified professional to avoid damage to this product.
 - This product is supplied raw and may discolour if exposed to direct sunlight for long periods. To avoid this, SAAS recommends colour matching this product to suit your vehicle's interior. (See below for painting tips)
- **BEFORE** installing, please check our website (shopsaas.com) for the latest fitting instructions. If the top left corner (v) number is different to website, please use instructions from website.

Fitting Steps:

- Check that your gauges fit into the pre-cut 52mm holes, some gauges might need the holes slightly enlarged.
- Remove the factory pillar trim (if fitted) and replace it with your new pillar pod. Some pillar pods may need slight modification to obtain a perfect fit.
- For pillar pod **SGP1102S**: Use the supplied rivet clips to attach the pillar pod to the factory pillar trim by drilling a 5mm hole at the top of the pillar pod. Once both trims are attached to each other, refit to vehicle.
- For pillar pod **SGP4204S**: Pillar pod is held in by the factory door moulding. 2 x rivet clips are supplied if extra support is required.
- Remove your new pillar pod and use the tips below if you wish to paint it.

Fitting and Painting Tips:

- **Factory speakers:** If your factory pillar trim has a speaker, it must be removed or repositioned before fitting the pillar pod.
- **Colour matching steps:** Use a scotch pad to lightly scuff the surface > clean with wax and grease remover > undercoat with plastic primer > spray top colour > do not clear coat.

Warranty Terms & Conditions:

SAAS Automotive Pty Ltd warrants this product against defects in factory workmanship and materials for a period of twelve (12) months from the date of original purchase. This warranty applies to the first retail purchaser, is non-transferable and covers only where the product has been subjected to normal use or service. Provision of this warranty shall not apply to any SAAS Automotive product that has been used for a purpose for which it is not designed, or which has been altered in any way that would be detrimental to the performance or life of the product, or misapplication, misuse, negligence or accident. Warranty claims to the manufacturer must be transportation prepaid and accompanied with dated proof of purchase. On any part or product found to be defective after examination by SAAS Automotive Pty Ltd, SAAS Automotive Pty Ltd will only repair or replace the merchandise through the original selling dealer or on a direct basis. SAAS Automotive Pty Ltd assumes no responsibility for diagnosis, removal and/or installation labour, loss of vehicle use, loss of time, inconvenience or any other consequential expenses. The warranties herein are in lieu of any other expressed or implied warranties, including any implied warranty of suitability, and any other obligation on the part of SAAS Automotive Pty Ltd, or the selling dealer.

For Further Assistance Email: tech@saasautomotive.com.au

SAAS Automotive PTY LTD
25 Metrolink Circuit West, Campbellfield,
Victoria 3061 Australia
ABN: 48166279670
ACN: 166279670
Phone: +61 3 9930 0100
Fax: +61 3 8339 2270
Email: tech@saasautomotive.com.au
Web: www.shopsaas.com