



25 Metrolink Circuit West Campbellfield
Victoria 3061 Australia
ABN: 48166279670 ACN: 166279670
Phone: +61 3 9930 0100
Fax: +61 3 8339 2270
Email: sales@saasautomotive.com.au

PART NO. SGA1007

Oil Sump Screw in Temperature Bung Adaptor 1/8 NPT

This adaptor allows an oil temperature sensor to be fitted into your engine oil sump or transmission oil pan.

FITTING GUIDE

SAAS highly recommends that the installation of the adaptor is fitted by a qualified automotive technician.

Step 1: Drain your oil and remove your oil pan. (Please ensure your oil is cool).

Step 2: Once the oil pan is removed find a flat surface in a suitable location and drill a 14mm hole so the adaptor can be installed.

Step 3: Using the diagram below install the adaptor according. SAAS recommends using a good quality non hardening thread lock sealer on the adaptor.

Step 4: Once the adaptor is installed reinstall you oil pan. Refill your oil pan with fluid and check or any oil leaks.

