

FORD RANGER PILLAR POD

Installation Instructions

Part No: SGP2104SC

Part No: SGP2104SLG

v20250513

Important notes before installing:

- **⚠ CAUTION ⚠**: Some vehicles have air bags fitted behind the pillars and may require special tools for removal. Before you proceed, refer to the vehicle's service manual for correct removal procedure. It is **YOUR** responsibility to make sure the air bags (if fitted) are not obstructed in any way, and function as per manufacturer's specifications!
- All installation work should be done by a qualified professional to avoid damage to this product.
- **BEFORE** installing, please check our website (**shopsaas.com**) for the latest fitting instructions. If the top left corner (**v**) number is different to website, please use instructions from website.

Fitting Steps:

- Check that your gauges fit into the pre-cut 52mm holes; some gauges might need the holes slightly enlarged.
- Remove the factory pillar trim handle followed by the pillar trim cover using a trim removal tool. Unplug the tweeter at the base of the factory trim and remove from vehicle.
- Unclip the tweeter from the factory trim and transfer it to the pillar pod.
- Line up the 2 locating tabs on the tweeter with the 2 slots in the pillar pod tweeter mount. Push the tweeter down until it seats and twist clockwise **slightly**. **⚠ DO NOT OVER TWIST THE TWEETER ⚠**
- Perform a trial fit with your gauges mounted to test for gauge depth and wiring clearance.
- Once you have confirmed clearances, plug the factory tweeter back in. Fit the pillar pod followed by the grab handle.

Fitting Tips:

- Gauges can be fitted using one of the methods below:
- If your gauge came with a U bracket, try this method first. Always check for clearance in the vehicle beforehand.
- Use some electrical tape or foam tape around the gauge body and press fit the gauges to the pod. Make sure not to press too hard or you may crack the pillar pod.

Warranty Terms & Conditions:

SAAS Automotive Pty Ltd warrants this product against defects in factory workmanship and materials for a period of twelve (**12**) months from the date of original purchase. This warranty applies to the first retail purchaser, is non-transferable and covers only where the product has been subjected to normal use or service. Provision of this warranty shall not apply to any SAAS Automotive product that has been used for a purpose for which it is not designed, or which has been altered in any way that would be detrimental to the performance or life of the product, or misapplication, misuse, negligence or accident. Warranty claims to the manufacturer must be transportation prepaid and accompanied with dated proof of purchase. On any part or product found to be defective after examination by SAAS Automotive Pty Ltd, SAAS Automotive Pty Ltd will only repair or replace the merchandise through the original selling dealer or on a direct basis. SAAS Automotive Pty Ltd assumes no responsibility for diagnosis, removal and/or installation labour, loss of vehicle use, loss of time, inconvenience or any other consequential expenses. The warranties herein are in lieu of any other expressed or implied warranties, including any implied warranty of suitability, and any other obligation on the part of SAAS Automotive Pty Ltd, or the selling dealer.

For Further Assistance Email: tech@saasautomotive.com.au

SAAS Automotive PTY LTD
25 Metrolink Circuit West, Campbellfield,
Victoria 3061 Australia
ABN: 48166279670
ACN: 166279670
Phone: +61 3 9930 0100
Fax: +61 3 8339 2270
Email: tech@saasautomotive.com.au
Web: www.shopsaas.com